

# Installation and Service Instructions

for use by heating contractor

**VIESMANN**

Communication with heating systems via BACnet or Modbus

## Vitogate 300



Certified as a component  
part for Viessmann boilers

*Product may not be exactly as shown*

**IMPORTANT**

**Read and save these instructions  
for future reference.**

**Safety, Installation and Warranty Requirements**

Please ensure that these instructions are read and understood before commencing installation. Failure to comply with the instructions listed below and details printed in this manual can cause product/property damage, severe personal injury, and/or loss of life. Ensure all requirements below are understood and fulfilled (including detailed information found in manual subsections).

■ **Product documentation**

Read all applicable documentation before commencing installation. Store documentation near boiler in a readily accessible location for reference in the future by service personnel.

▶ *For a listing of applicable literature, please see section entitled "Important Regulatory and Safety Requirements".*



■ **Warranty**


Information contained in this and related product documentation must be read and followed. Failure to do so renders the warranty null and void.



■ **Licensed professional heating contractor**

The installation, adjustment, service and maintenance of this equipment must be performed by a licensed professional heating contractor.

▶ *Please see section entitled Safety and "Important Regulatory and Installation Requirements".*



■ **Advice to owner**

Once the installation work is complete, the heating contractor must familiarize the system operator/ultimate owner with all equipment, as well as safety precautions/requirements, shutdown procedure, and the need for professional service annually before the heating season begins.

	Page
<b>Safety</b>	<b>Safety, Installation and Warranty Requirements.....</b> 2
	Product documentation.....2
	Licensed professional heating contractor.....2
	Advice to owner.....2
	Warranty.....2
<b>General Information</b>	<b>Important Regulatory and Installation Requirements.....</b> 4
	Approvals.....4
	Codes.....4
	Working on the equipment.....4
	Power supply.....4
	<b>About these Installation Instructions.....</b> 4
<b>Installation</b>	<b>Preparing for Installation.....</b> 5
	<b>Wall Mounting (with enclosure).....</b> 6
	<b>Power Supply Connections for Wall Mounting (with enclosure).....</b> 7
	<b>CM2 Junction Box DIN Rail Mounting.....</b> 8
	<b>Power Supply Connections for CM2 Junction Box.....</b> 9
	<b>Vitogate and Power Supply Location for CA3.....</b> 10
	<b>Power Supply Connections for CA3.....</b> 11
<b>Connections</b>	<b>Power Supply.....</b> 12
	<b>Connection Diagram.....</b> 12
	<b>Making the LON Connection.....</b> 13
<b>Commissioning</b>	<b>Integrating the Vitotronic Unit into LON.....</b> 14
	<b>Updating LON Participant List.....</b> 14
	<b>Carrying out Participant Check.....</b> 14
	<b>Commissioning.....</b> 15
<b>Parts</b>	<b>Parts List.....</b> 16
<b>Specifications</b>	<b>Vitogate 300, Type BN/MB.....</b> 17
	<b>Power Supply Unit.....</b> 17

# Important Regulatory and Installation Requirements

### Approvals

Viessmann boilers, burners and controls are approved for sale in North America by CSA International.

### Codes

The installation of this unit shall be in accordance with local codes. In the absence of local codes, use:

- CSA C22.1 Part 1 and/or local codes in Canada
- National Electrical Code ANSI/NFPA 70 in the U.S.

Always use latest editions of codes.

The heating contractor must comply with the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1 where required by the authority having jurisdiction.

### Working on the equipment

The installation, adjustment, service, and maintenance of this product must be done by a licensed professional heating contractor who is qualified and experienced in the installation, service, and maintenance of hot water boilers. There are no user serviceable parts on the boiler, burner, or control.

### Power supply

Install power supply in accordance with the regulations of the authorities having jurisdiction or, in absence of such requirements, in accordance with National Codes. Viessmann recommends the installation of a disconnect switch to the 120V power supply outside of the boiler room.


Ensure main power supply to equipment, the heating system, and all external controls have been deactivated. Close main oil or gas supply valve. Take precautions in both instances to avoid accidental activation of power during service work.

- ▶ Please carefully read this manual prior to attempting installation. Any warranty is null and void if these instructions are not followed.

For information regarding other Viessmann System Technology componentry, please reference documentation of the respective product.

We offer frequent installation and service seminars to familiarize our partners with our products. Please inquire.

- ▶ The completeness and functionality of field supplied electrical controls and components must be verified by the heating contractor. These include low water cut-offs, flow switches (if used), staging controls, pumps, motorized valves, air vents, thermostats, etc.

	<p><b>! WARNING</b></p> <p>Turn off electric power supply before servicing. Contact with live electric components can cause shock or loss of life.</p>
--	--

## About these Installation Instructions

- !** Take note of all symbols and notations intended to draw attention to potential hazards or important product information.

<b>! WARNING</b>
Warnings draw your attention to the presence of potential hazards or important product information.

- ▶ Indicates an imminently hazardous situation which, if not avoided, could result in death, serious injury or substantial product/property damage.

<b>! CAUTION</b>
Cautions draw your attention to the presence of potential hazards or important product information.

- ▶ Indicates an imminently hazardous situation which, if not avoided, may result in minor injury or product / property damage.

<b>IMPORTANT</b>
------------------

- ▶ Helpful hints for installation, operation or maintenance which pertain to the product.



- ▶ This symbol indicates to note additional information
- ▶ This symbol indicates that other instructions must be referenced.

## Preparing for Installation

### Intended use

Install and operate Vitogate products as intended in conjunction with the electronic control units and controllers for the Viessmann heat and power generators designed for this system, giving due consideration to the associated installation, service and operating instructions. In particular, observe the current and voltage specifications for connections and hook-ups.

Use of the Vitogate products are exclusively for monitoring, operating and optimizing systems with the user and communication interfaces specified for this purpose in the relevant printed documentation.

In the case of communication interfaces, ensure on site that the system requirements specified in the product documentation are met at all times for every transfer medium employed. Only use the specified components for the mains power supply (e.g. mains power adaptors).

### Product information


The Vitogate 300, type BN/MB gateway is designed to integrate the Vitotronic control units using the integral LON communication module (accessory\*) to BACnet or Modbus control systems. For supported appliances/ devices and further information, see [www.vitogate.info](http://www.vitogate.info). The Vitogate 300, type BN/MB must be integrated into the BACnet or Modbus control system by an authorized contractor.

\* Depending on the relevant control, this may be an additional accessory item.

### Functions

The Vitogate 300, type BN/MB enables system users to utilize the following functions in conjunction with a BACnet or Modbus control system:


- Adjustment of the heating system operating states (standby/heating mode)
- Setting heating system parameters (temperature setpoint)
- Relaying fault and error messages



### Legend

- (A) Power supply unit
- (B) Vitogate 300

Vitogate 300, type BN/MB and its power supply unit are suitable for mounting on a DIN rail (TS35 Top Hat Rail 35 mm x 15 mm or 35 mm x 7.5 mm).

**Wall Mounting (with enclosure)****Legend**

- (A) Module enclosure  
(complete with a Vitogate 300 and power supply unit)
- (B) Enclosure cover
- (C) Wall anchors (field supplied)
- (D) Mounting screws (field supplied)

## Power Supply Connections for Wall Mounting (with enclosure)


**WARNING**

Incorrect core allocation can result in serious injury and damage to the appliance. Take care not to interchange wires "L" and "N"

**Power supply independent of the mains isolator**

When the heating system is switched off via the mains isolator, the Vitogate 300 remains on, while the Vitotronic control unit is switched off.

No data is transferred to the BACnet or Modbus control system.




**Legend**

- (A) Vitogate 300
- (B) Power supply 100 to 240V~, 45 to 65 Hz
- (C) Mains isolator
- (D) Power supply unit
- (E) RS 485 connection:  
Interface for BACnet MS/TP or Modbus RS 485
- (F) 24V power supply connection


The enclosure mounted version comes with a pre-wired power supply unit which includes connection to the Vitogate 300 module and a standard 3 prong AC plug.

**CM2 Junction Box DIN Rail Mounting**



1. Measure to allow for clearances as shown, then use the DIN rail as a template to mark and centre punch hole locations.

2. Drill two holes  $\varnothing$  3/16 in.




3. Mount the DIN rail (A) with the mounting hardware to the inside of the junction box as shown.

4. Mount the Vitogate 300 (C) to junction box side DIN rail (A) and mount the power supply unit (B) to the junction box main DIN rail (D).

**Legend**

- (A) Junction box side DIN rail 3 in. (75 mm)
- (B) Power supply unit
- (C) Vitogate 300
- (D) Junction box main DIN rail

## Power Supply Connections for CM2 Junction Box




Connections to Junction Box

1. Connect the 24VDC power supply cable (supplied) to the power supply unit, with the red or brown wire to the + terminal and the black or blue wire to the - terminal as shown.
2. Connect the other end of the 24VDC power supply cable (supplied), into the Vitogate 300, with the red or brown wire to the + 24 terminal and the black or blue wire to the GND terminal as shown.  
**Note:** The power supply plug in the Vitogate 300 can be easily removed to aid with wiring connection.
3. Make a connection from the power supply unit L and N connections to any vacant L and N connections of the junction box terminals 14 thru 17.

### Power supply via the mains isolator

When the heating system is switched off via the mains isolator, the Vitogate 300 and the Vitotronic control unit are also switched off.  
No data is transferred to the BACnet or Modbus control system.



### Legend

- (A) Vitogate 300
- (B) Power supply unit
- (C) RS 485 connection:  
Interface for BACnet MS/TP or Modbus RS 485
- (D) Junction box main DIN rail
- (E) Junction box side DIN rail
- (F) Junction box




### WARNING

Incorrect core allocation can result in serious injury and damage to the appliance. Take care not to interchange wires "L" and "N"



For more details refer to the Installation and Service Instructions applicable to the boiler.

**Vitogate and Power Supply Mounting Location for CA3/CA3B**




1. Mount the Vitogate 300 (B) to junction box main DIN rail (C) and mount the power supply unit (A) to the junction box main DIN rail (C).

**Legend**

- (A) Power supply unit
- (B) Vitogate 300
- (C) Ancillary DIN rail

## Power Supply Connections for CA3/CA3B



1. Connect the 24VDC power supply cable (supplied) to the power supply unit, with the red or brown wire to the + terminal and the black or blue wire to the - terminal as shown.

2. Connect the other end of the 24VDC power supply cable (supplied), into the Vitogate 300, with the red or brown wire to the +24 terminal and the black or blue wire to the GND terminal as shown.

**Note:** The power supply plug in the Vitogate 300 can be easily removed to aid with wiring connection.

3. Make a connection from the power supply unit L and N connections to any vacant L and N connections of the junction box terminals 12 thru 14.

### Power supply via the mains isolator

When the heating system is switched off via the mains isolator, the Vitogate 300 and the Vitotronic control unit are also switched off.

No data is transferred to the BACnet or Modbus control system.

### **!** WARNING

Incorrect core allocation can result in serious injury and damage to the appliance. Take care not to interchange wires "L" and "N"



For more details refer to the Installation and Service Instructions applicable to the boiler.

### Legend

- (A) Vitogate 300
- (B) Power supply unit
- (C) RS 485 connection:  
Interface for BACnet MS/TP or Modbus RS 485
- (D) Ancillary DIN rail (within Vitotronic 300 GW6C housing)
- (E) External accessories DIN rail
- (1) Red or brown wire
- (2) Black or blue wire
- (3) Black or blue wire
- (4) Red or brown wire

# Power Supply

### Direct power supply



## WARNING

Incorrectly executed electrical installations can result in injuries from electrical current and in equipment damage.

Connect the power supply (if required) and implement all grounding measures (e.g. RCD circuit) in accordance with the following regulations:

- In Canada all electrical wiring is to be done in accordance with the latest edition of CSA C22.1 Part 1 and/or local codes. In the U.S. use the National Electrical Code ANSI/NFPA 70. The heating contractor must also comply with both the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1, and the Installation Code for Hydronic Heating Systems, CSA B214-01, where required by the authority having jurisdiction.
- Connection requirements specified by your local power supply utility
- Protect the power cable with max. 12A

## IMPORTANT

Protect the Vitogate 300 power cable with the appropriate fuse.

### Isolators for non-grounded conductors

- The mains isolator (if installed) must simultaneously isolate all non-grounded conductors from the mains.
- If no mains isolator is installed, all non grounded conductors must be isolated from the mains by the upstream circuit breaker.



## WARNING

Incorrect core allocation can result in serious injury and damage to the appliance.  
Never interchange cores "L" and "N".



## CAUTION


An incorrect phase sequence can cause damage to the appliance. Check for phase equality with the power supply connection of the control unit.



## WARNING

The absence of component grounding in the system can lead to serious injury from electrical current if an electrical fault occurs. Connect the appliance and pipework to the equipotential bonding of the building in question.

## Connection Diagram



### Legend

- LON status Illuminates green
- RX Flashes yellow: Device receives data.
- TX Flashes yellow: Device sends data.
- Power Illuminates green: Power ON, operating voltage 'live'
- Status\* Multi color status LED: red, green, orange

- (A) DIP switch:
  - 1 - Bias voltage for RS 485 interface
  - 2 - Bias voltage for RS 485 interface
  - 3 - 120 Ω terminator
- (B) RS 485 connection: Interface for BACnet MS/TP or Modbus RS 485 (this plug in the Vitogate 300 can be easily removed to aid with wiring connection).
- (C) Power supply connection 24VDC
- (D) LAN connection with PC/Laptop or BACnet IP or Modbus TCP/IP
- (E) LON connection, 2 piece RJ 45 sockets, screened
- (F) USB connection for software updates

### Meaning of the status\* indication

Illuminates green	Reset is being held down
Flashes green	Standard operation
Flashes green/red	DHCP server enabled
Illuminates orange	Indication during re-start
Flashes orange	Indication following the start phase when there is no gateway configuration
Flashes red	Indication in the case of BUS errors in the MS/TP network (e.g. framing errors)
Illuminates red	Indication prior to a reset while files are being connected.

### Making the LON Connection

The Viessmann LON is designed for "Line" BUS topology with a terminal end resistor at both ends (accessories). Further information can be found in the "Viessmann LON manual"; see [www.viessmann.de/lon](http://www.viessmann.de/lon).

The transfer distances for LON are subject to the electrical properties of the respective cable. For this reason, only use the specified cable types. Use only one cable type within each LON.

Cable types (on site):


- 2-core cable, CAT5, screened
- JY(St)Y 2 x 2 x 0.8 mm (telephone cable)

Observe the cabling requirements for the operation of the LON interface FTT 10-A (see [www.echelon.com](http://www.echelon.com)).

All Viessmann appliances are connected with RJ45 connectors. The Viessmann LON always requires cores "1" and "2" plus the screen. The cores are interchangeable. The installation is therefore reverse polarity protected.

**Note:** When connecting devices and routing cables, observe the relevant safety requirements. Ensure the safe electrical separation of all on-site components (including PC/laptops).


#### Connection with LON cable



##### Legend

- (A) Vitotronic control unit
- (B) Vitogate 300
- (C) Terminal end resistor
- (D) LON cable, 23 ft. (7 m) long


#### Connection with LON cable and LON coupling



##### Legend

- (A) Vitotronic control unit
- (B) Vitogate 300
- (C) Terminal end resistor
- (D) LON cable, 23 ft. (7 m) long:  
Max. 3 cables between 2 devices
- (E) LON extension jack


#### Connection with on-site cable and LON plug



##### Legend

- (A) Vitotronic control unit
- (B) Vitogate 300
- (C) Terminal end resistor
- (D) RJ45 male plug end
- (E) On-site cable (field supplied)
- (F) Up to 99 participants

#### Connection with LON cable, on-site cable and LON socket



##### Legend

- (A) Vitotronic control unit
- (B) Vitogate 300
- (C) Terminal end resistor
- (D) LON cable, 23 ft. (7 m) long
- (E) On-site cable (field supplied)
- (F) LON sockets
- (G) Up to 99 participants

# Integrating the Vitotronic Control Unit into LON

The LON communication module (accessory\*) must be installed into the Vitotronic control unit.

\* Depending on the relevant control, this may be an additional accessory item.

**Note:** The data transfer via LON can take several minute

**LON system number and participant number**


Set LON system number, LON participant number and further functions via code 2.



Refer to the relevant Vitotronic control unit Service Instructions and the following table.

**Note:** In the same LON system, each number can only be allocated once.  
Only one Vitotronic control unit per system may be programmed as the fault manager.

Example: Single boiler system with Vitotronic 300, Vitotronic 200-H heating circuit control unit downstream and Vitogate 300, type BN/MB



Participant no. 1 Code "77:1"	Participant no. 10 Code "77:10"	Delivered condition Vitogate 300: Participant no. 97
Control unit is fault manager Code "79:1"	Control unit is not fault manager. Code "79:0"	Device is fault manager.
Viessmann system number Code "98:1"	Viessmann system number Code "98:1"	--
LON participant fault monitoring Code "9C:20"	LON participant fault monitoring Code "9C:20"	--

## Updating LON Participant List



Refer to the relevant Vitotronic control unit Installation and Service Instructions.

## Carrying out Participant Check



Refer to the relevant Vitotronic control unit Installation and Service Instructions.

## Commissioning

Devices required for commissioning:

- PC/laptop with the following equipment:
  - Minimum monitor resolution 1024 x 768
  - Integral or external Ethernet network module
  - PDF Reader
- Supported web browsers:
  - MS Internet Explorer V 7 or higher
  - Mozilla Firefox V 2 or higher
  - Mobile Safari V 3.1 or higher
  - Google Chrome V 18.0 or higher
- Twisted pair network cable

### Enabling the DHCP server

Dynamic Host Configuration Protocol (DHCP) makes IP addresses available to clients on request.

If the computer has been set up as DHCP client (standard setting), the DHCP server of the Vitogate 300 can be used to provide an IP address.

Hold down the reset button on the Vitogate 300 for at least 5 sec, but no longer than 10 sec.

The DHCP server has been enabled once the LED LON status flashes green/red alternately.

**Note:** The DHCP server does not need to be enabled if a manual IP address is to be used.

### Creating an Ethernet network

Connect the computer network module by means of a twisted pair network cable with the RJ45 connection of the Vitogate 300.

### Creating a connection with the Vitogate 300 configuration webserver


An IP address is automatically assigned to the computer if the DHCP server has been enabled.

If a manual IP address is to be used, make the following settings on the computer:


- IP address: 169.254.0.2 (or higher)
- Subnet mask: 255.255.0.0
- Standard gateway: Leave blank.

For Vitogate 300 equipped with firmware patch, to access the webserver requires the additional step of pressing and holding the reset button for 2 seconds (location of reset button can be found on page 12). The web server will then remain active for 30 minutes, when the 30 minutes expires access to the webserver will be disabled.

### Commissioning



XXXXXXXXXXXXXXXXXXXX  
MAC: XX-XX-XX-XX-XX-XX



**Hinweis**  
Das Passwort in der Montage- und Serviceanleitung Vitogate 300, Typ BN/MB, ist nicht gultig.  
Das Passwort verwenden, das sich auf dem Aufkleber am Gerat befindet.

**Note**  
The password in the installation and service instructions for Vitogate 300, type BN/MB is not valid.  
Use the password on the label on the device.

**Remarque**  
Le mot de passe figurant dans la notice de montage et de maintenance Vitogate 300, type BN/MB n'est pas valable.  
Utiliser le mot de passe se trouvant sur l'auto-collant de l'appareil.

6216489 6/2023

#### Calling up the Vitogate 300 configuration webserver

Open the Vitogate 300 configuration screens:

Start web browser:

- Enter IP address 169.254.0.1 into the address line.
- User name: vitogate
- Password: viessmann\*  
You can change the password later.

\*Beginning in the second half of 2024, all Vitogate 300 units will be shipped with a unique password. This password can be found on the side of the Vitogate unit and on the metal enclosure in which the Vitogate is installed.

The label includes a barcode, the password, and the device's MAC address.

Note: after performing a factory reset, the password will be reset to "viessmann".

The gateway default screen is called up.

Note: The configuration screens are described in the integral Vitogate 300 online help.

**Parts List**

**Parts**


- 0001 Replacement module
- 0002 LON connecting cable, 7m RJ45
- 0003 Power module, 120-240/24V
- 0005 Harness, power 24V
- 0006 Technical Literature Set

**Other Parts** (not illustrated)

- 0100 Accessory pack, DIN rail and fasteners \*1
- 0101 Power cable, 120/1/60 2m \*2
- 0103 Installation/Service Instructions
- 0104 Online Help Guide
- 0105 Parts List

\* 1 Only for Vitogate 7559705 for Vitocrossal 200.

\* 2 Only for Vitogate 7559706 compact wall-mount unit.




**Vitogate 300, Type BN/MB**

Mains voltage	12 to 24V AC/DC
Power consumption	Max. 320 mA
Rated output	Max. 3.85 W
Frequency range	47 to 63 Hz
Permiss. ambient temperature - During operation 32 to 113°F (0 to 45°C) - During transport and storage	32 to 113°F (0 to 45°C) 14 to 149°F ( - 10 to +65°C)
Permiss. humidity - During operation 20 to 80% - During storage and transport	20 to 80% relative humidity, non-condensing 10 to 85% relative humidity, non-condensing
Dimensions (height x width x depth)	4 x 2 x 2.75 in. (100 x 48 x 70 mm)
Installation	DIN rail (TS35 Top Hat Rail 35 mm x 15 mm or 35 mm x 7.5 mm)
Power supply unit	STEP-PS 1AC/24DC 0.75/FL.

**Power Supply Unit**

Rated voltage	100 to 240V ~
Rated frequency	45 to 65 Hz
Output voltage	24VDC ± 1%
Output current max.	1.4A
Permiss. ambient temperature - Operation > 131°F (> 55°C) line loss - Storage and transport	-13 to 158°F (-25 to +70°C) -40 to 185°F (- 40 to +85°C)
Max. humidity	95% relative humidity at 77°F (25°C), non-condensing
Dimensions (height x width x depth)	6 x 1.4 x 1.7 in. (150 x 36 x 43 mm)
Installation	DIN rail (TS35 Top Hat Rail 35 mm x 15 mm or 35 mm x 7.5 mm)





Printed on environmentally friendly  
(recycled and recyclable) paper.



Technical information subject to change without notice.

Scan for digital copy of this document



Viessmann Manufacturing Company (U.S.) Inc.  
 45 Access Road  
 Warwick, Rhode Island · 02886 · USA  
 TechInfo Line 1-888-484-8643  
 1-800-288-0667 · Fax (401) 732-0590  
 www.viessmann-us.com · info@viessmann-us.com

Viessmann Manufacturing Company ULC  
 750 McMurray Road  
 Waterloo, Ontario · N2V 2G5 · Canada  
 TechInfo Line 1-888-484-8643  
 1-800-387-7373 · Fax (519) 885-0887  
 www.viessmann.ca · info@viessmann.ca