

# Socket frame

TapHome design socket frame. Compatible with Legrand Mosaic. Fenix NTM material – white, anthracite, black. Mounting plate sold separately.



## Quick Facts

Dimensions	80 × 80 × 8 mm
Operating temperature	-10 ... 60 °C
IP rating	IP20

Stylish socket frame is made of the same material as switches and controls and is dimensionally compatible with them.

Attention: The mounting plate must be ordered separately.

## Product Variants

Order Code	Farba	EAN
SOCKET-C-F-1.0-AN	Antracit	 8586022952517
SOCKET-C-F-1.0-BE	Běžová	 8586022942532
SOCKET-C-F-1.0-BK	Čierna	 8586022942525
SOCKET-C-F-1.0-WH	Biela	 8586022932502

## Technical Specifications

---

### GENERAL

Material	Fenix NTM (anti-fingerprint, super-matte)
Compatibility	Legrand Mosaic (230V sockets, USB chargers)
Colors	Biela, Antracit, Čierna, Béžová

## Compatible with Legrand Mosaic

---

Attention: does not include the socket part itself. It must be purchased separately.

- All 230V sockets are compatible
- Separate USB chargers are compatible
- The LAN connectors are partially compatible - they fit, but are not firmly clicked
- The socket with the USB charger has an incompatible shape and cannot be used
- The lighting has a different snap-on system and is not compatible

## Color versions

---

- White: Fenix NTM 0032 Bianco Kos, RAL CLASSIC / 9016
- Anthracite: Fenix NTM 0724 Grigio Bromo, RAL CLASSIC / 7012
- Black: Fenix NTM 0720 Nero Ingo, RAL DESIGN / 000 25 00

## Installation and Disassembly

---

**Installation:** First, secure the installation frame onto the KU installation box, ensuring that the arrow labeled “TOP” points upwards and the ventilation openings are facing downwards. Then, snap the product onto the installation frame by first inserting the hooks on the top of the product into the frame, and then gently pressing to secure the bottom part. **Disassembly:** Insert a narrow flathead screwdriver into the small notch on the hook at the bottom of the installation frame. Gently pry the hook out of its socket and hold it in place with your hand to prevent it from snapping back into its original position. Repeat this process on the hook on the other side, which will release the bottom part of the product, allowing you to remove it completely.

### [Mounting and dismounting](#)



Product page

<https://hardware.taphome.com/socket/>

